



# HOW TO: ROLLEN WECHSELN

## 1. Austausch der Kunststoffhalterung der Rollen

Wenn die Kunststoffhalterung der Rollen beschädigt ist, müssen die vorhandenen Nieten ausgebohrt werden. Ersetzen Sie diese anschließend durch die beiliegenden neuen Nieten (4 Nieten pro Rad).

## 2. Ältere Werkzeugkoffermodelle

Bei älteren Modellen ist ggf. eine Verschraubung der Rollen nicht vorgesehen. In diesem Fall muss das gesamte Gehäuse ausgetauscht werden.

## 3. Einzelner Rollentausch

- 1 Entfernen Sie die Rolle, indem Sie einen Inbusschlüssel Größe 5 und einen Gabelschlüssel Größe 8 verwenden.

- 2 Setzen Sie die neue Rolle ein und ziehen Sie die Schraube fest.



Montagematerial im Überblick



# HOW TO: CHANGING WHEELS

## 1. Replacing the Plastic Wheel Mount

If the plastic mount of the wheels is damaged, the existing rivets must be drilled out and replaced with the supplied new rivets (4 rivets per wheel).

## 2. Older Tool Case Models

In older models of the tool case, the wheels may not be screwed in place. In this case, the entire housing must be replaced.

## 3. Single Wheel Replacement

- 1 Remove the wheel using a size 5 Allen key and a size 8 open-end wrench.
- 2 Insert the new wheel and tighten the screw securely.



Overview of mounting materials



JETZT  
VIDEOANLEITUNG  
ANSEHEN ➔

WATCH VIDEO  
TUTORIAL NOW ➔



# PARAT®