



## HOW TO: SCHLOSS WECHSELN

- 1 Als Werkzeug wird ein Torx-Schraubendreher in Größe T20 benötigt.
- 2 Lösen Sie zunächst die beiden Schloss-Schrauben im Innenrahmen des Koffers mithilfe des Torx T20-Schraubendrehers.
- 3 Entnehmen Sie das alte Schloss vorsichtig und setzen Sie das neue Schloss so ein, dass die Kippseite nach außen zeigt.
- 4 Verwenden Sie selbstschneidende Schrauben, um das neue Schloss sicher zu befestigen. Ziehen Sie die Schrauben gleichmäßig und handfest an – nicht mit übermäßiger Kraft, um das Material nicht zu beschädigen.



## HOW TO: CHANGING THE LOCK

- 1 A Torx screwdriver size T20 is required for this task.
- 2 First, loosen the two lock screws in the inner frame of the case using the T20 Torx screwdriver.
- 3 Carefully remove the old lock and insert the new lock so that the hinge side faces outward.
- 4 Use self-tapping screws to securely fasten the new lock. Tighten the screws evenly and firmly by hand—do not use excessive force to avoid damaging the material.

**JETZT  
VIDEOANLEITUNG  
ANSEHEN ➔**

**WATCH VIDEO  
TUTORIAL NOW ➔**



**PARAT®**