



## HOW TO: GRIFF WECHSELN (CLASSIC SERIE)

- 1 Feder einsetzen: Die Feder in die Raststücke drücken.
- 2 Griff vorbereiten: Den Griff in die Griffböckchen einlegen.
- 3 Raststück montieren: Das Raststück mit der Feder in die Griffböckchen schieben.
- 4 Komponenten befestigen: Die zusammengesetzten Teile aus den Schritten 1–3 auf die Griffschiene setzen, anschließend auf den Alurahmen legen und mit den mitgelieferten Schrauben befestigen.
- 5 Schrauben anziehen: Die beiden Schrauben (4 × 16 mm) mit einem Drehmoment von 1,5 Nm festziehen.




## HOW TO: CHANGING THE HANDLE (CLASSIC SERIES)

- 1 Insert the spring: Press the spring into the locking pieces.
- 2 Prepare the handle: Place the handle into the handle brackets.
- 3 Mount the locking piece: Slide the locking piece with the spring into the handle brackets.
- 4 Attach the components: Position the assembled parts from steps 1–3 onto the handle rail, then place them on the aluminum frame and secure with the supplied screws.
- 5 Tighten screws: Tighten the two screws (4 × 16 mm) to a torque of 1.5 Nm.

**JETZT  
VIDEOANLEITUNG  
ANSEHEN** ➔

**WATCH VIDEO  
TUTORIAL NOW** ➔



**PARAT®**